



Attach 1 1/4" x 1 1/4" angles to cover edges of slats.